

Scout Camera Box Quick Release Kit

SKU: QR_SCOUT_BOX

The quick release plate attaches to the camera.



This clamp holds the camera and quick release plate. It is held in place with the two included screws.



Two 1/8" spacers are included for centering the lens. This may be required for certain cameras and/or lenses.



These rails are attached to the inside of the camera box per the template instructions.



When using a small camera body like a Canon Rebel use both included spacers, when using a larger camera like a Canon 6D or Nikon D600 no spacers are required. The same screws can be used to mount the Arca Clamp with or without spacers.

Cognisys, Inc.
459 Hughes Dr.
Traverse City, MI 49696

Phone: 231-943-2425
E-mail: support@cognisys-inc.com
www.cognisys-inc.com