

RECEIVER



Press to turn on Scout.
Press and hold to turn off.



Enter button - Use to change settings or enter menus.





Up and Down buttons - Use for menu navigation and number entry.

TRANSMITTER



Transmit Power button - 2 levels Press to change.



Transmit Speed button - 3 levels Press to change.

Base Transmitter equipped with power button only.





Getting Started:

- 1. Remove 4 phillips screws from the bottom of both the transmitter and receiver. Install 6 AA batteries in each.
- 2. Power on both the Scout Transmitter and Receiver.
- 3. Turn on LED Alignment Press enter, then enter again.
- 4. Face the transmitter and receiver towards each other. When they are aligned the Receiver LED will flash Red.
- 5. The LED will turn green when the beam is interrupted and LED Alignment is on. If LED Alignment is off the LED will turn red on trigger.
- 6. Connect your camera as shown above.

There are many other settings and modes you can use. Be sure to check out the owner's manual for more details. As always, please let us know if you have any questions. We're glad to help!

Phone: 248-365-0052 Toll-Free: 888-746-3731